

## GEU6603ELPOS

This electronic dynamo regulator must only be used on POSITIVE ground cars!

It replaces the mechanical regulator GEU6603 directly – no alterations are required at all.

This regulator is fitted with a standard quick blow 30mm glass fuse. In the event of an external fault or overloading, the fuse will blow. Do not use a fuse rated higher than the one fitted if it ever needs to be replaced!

Your dynamo must be polarized before you use this regulator. Disconnect the two wires (D&F) from your dynamo, run a thin wire from the battery negative terminal to the connector F on your dynamo and connect for 5 seconds. Job done – your dynamo is now polarized for use on a positive ground car.

